



EE772 Series

**FLOW METER for
COMPRESSED AIR and GASES**



Manual

Hardware and Software

YOUR PARTNER IN SENSOR TECHNOLOGY



ELEKTRONIK®
Ges.m.b.H.

E+E Elektronik® Ges.m.b.H. doesn't accept warranty and liability claims neither upon this publication nor in case of improper treatment of the described products.

The document may contain technical inaccuracies and typographical errors. The content will be revised on a regular basis. These changes will be implemented in later versions. The described products can be improved and changed at any time without prior notice.

**© Copyright E+E Elektronik® Ges.m.b.H.
All rights reserved.**

**USA
FCC notice:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the installation manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

**CANADIAN
ICES-003 notification:**

This Device B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Table of contents - HARDWARE

1. GENERAL	4
1.1. Safety Instructions	4
1.1.1. Intended Use	4
1.1.2. Installation, start up and control	5
1.2. Environmental aspects	5
2. PRODUCT DESCRIPTION	6
3. INSTALLATION	7
3.1. Mounting dimensions	7
3.2. Determining installation site	8
3.3. Installation position	8
3.4. Required length of straight pipe	9
3.5. Assembly of the measurement section	10
3.5.1. Assembly without flow meter, but with screw cap instead (blind cap)	10
3.6. Installation of the flow meter sensing probe	10
3.6.1. Flow direction	10
3.6.2. Installation of the sensing probe into the gauge mounting block	11
3.6.3. Installation of the sensing probe into the gauge mounting block with hot tap valve	12
4. ELECTRICAL CONNECTIONS	13
4.1. Connection diagram	13
4.1.1. Relay and pulse output, internal switching	13
4.1.2. Connection with optional plug for power supply and outputs (order code Q)	13
4.2. Bus Output (optional)	14
4.2.1. M-Bus (Meter-Bus)	14
4.2.2. Modbus RTU	15
4.2.3. Data Transmission	15
4.2.4. Addressing	15
5. CONTROL COMPONENTS	16
5.1. Jumper J1 and J2	16
5.2. Digital interface USB (for configuration)	16
5.3. Display / Indicator with keypad (optional)	16
5.3.1. Indication of the analogue and pulse output	17
5.3.2. Indication of the switch output	17
5.3.3. Indication of the MIN / MAX values	17
5.3.4. Reset of the consumption counter or the MIN / MAX value	18
5.3.5. Maximum consumption counter	18
6. ERROR MESSAGES	18
7. MAINTENANCE	19
7.1. Removal of the sensing probe of the gauge mounting block	19
7.2. Removal of the sensing probe of the gauge mounting block with hot tap valve	19
7.3. Cleaning of the sensor of the flow meter	19
8. REPLACEMENT PARTS / ACCESSORIES	19
8.1. Order Code Replacement Sensor	19
9. TECHNICAL DATA	20
9.1. Factory setting of outputs	21

Table of contents - SOFTWARE

1. General	22
2. Installation	23
2.1. Configuration of the USB Interface (VirtualCOM)	23
3. User Interface	24
4. Menu toolbar	25
4.1. File	25
4.2. Transmitter	25
4.3. Extras	25
5. Input Screen	25
5.1. Output 1, Output 2	25
5.1.1. Output mode	25
5.1.2. Measurand	25
5.1.3. Units	25
5.1.4. Output mode – analogue	26
5.1.5. Output mode – switch (relay)	26
5.1.6. Output mode – pulse	27
5.2. Minimum flow shutdown	27
5.3. Display	28
5.4. Adjustment	28
5.4.1. 1-point adjustment	28
5.4.2. 2-point adjustment	29
5.4.3. Reset to factory settings	30
5.5. Measuring values overview	30
5.5.1. Reset of the MIN / MAX values	30
5.5.2. Reset of the consumption counter (totalizer)	30
5.6. Setting up Process Parameters	30
5.6.1. Change the Process Gas	30
5.6.2. Changing the standard conditions	31
5.6.3. Pressure compensation	31
5.7. External pressure transmitter for pressure compensation	31
5.8. Bus configuration	31

1. GENERAL

This manual is a part of the scope of supply and serves to ensure optimal operation and functioning of the equipment.

For this reason, the manual must be read before start-up.

Therefore, it is necessary that this manual is read and understood by those responsible for the handling, installation, and maintenance of the equipment.

This manual may not be used for competitive purposes or passed on to third parties without the written consent of E+E Elektronik® Ges.m.b.H.

It is permitted to make copies for personal use.

All information, technical data and illustrations contained in these instructions are based on information available at the time of publication.

Symbol Clarification



This symbol indicates safety instructions.

The safety instructions have to be carried out unconditionally. If disregarded loss, injury, or damage may be inflicted to people and property. In any case E+E Elektronik® Ges.m.b.H. cannot be held responsible.



This symbol indicates attention.

The note should be observed to achieve an optimal functioning of the equipment.

1.1. Safety Instructions

1.1.1. Intended Use

The flow meter is intended to be used for the measurement of air and other non-corrosive gases in pipelines only. Consult the factory first before the measurement of wet or filthy gases.

The design of the flow meter allows for the EE772 to be installed in a pressurized system up to PN40 – is 40 bar (580 psi).



Prior to the start of the installation, the system has to be depressurized. Before the installation or removal of the sensing probe or the screw cap, the gauge mounting block should be closed.

Mounting, electrical installation, putting in operation and maintenance should only be done by qualified personnel.

The use of the flow meter EE772 in any other way than described in this manual bears a safety risk for people and the entire measurement installation and is therefore not allowed.

The manufacturer cannot be held responsible for damages as a result of incorrect handling, installation, and maintenance of the equipment.

To avoid health risks or damage to the equipment, the installation should not be operated on with tools, which are not specifically mentioned or described in this manual.

Excessive mechanical stress and inappropriate handling must be avoided.

A short interruption of the flow using the measurement ball valve cannot be avoided when exchanging the sensing probe.

The flow meter can only be utilized in accordance with the conditions defined in the technical data. Otherwise, inaccuracies of the measurement will occur and equipment failures cannot be ruled out.

For the safety of the user and for the functionality of the equipment the recommended steps by the manufacturer to put into operation, to test and to maintain should be taken and completed.

1.1.2. Installation, start up and control

The flow meter is designed and built in accordance with the latest state in technology, tested adequately and has been shipped from the factory in good order and condition.

As the user, you are responsible to comply with all applicable safety regulations amongst others:

- Instruction for the installation
- Local standards and codes

The manufacturer has taken all measures to assure safe operation. The user has to make sure that the equipment is positioned and installed in such a way that safe operation is not impaired.

The equipment is tested in the factory and shipped in good order and condition.

This manual contains information and notes of caution, which have to be adhered to by the user to assure a safe operation.

- Mounting, electrical installation, putting into operation and maintenance should only be done by qualified personnel. The plant operator should authorize qualified personnel to operate on the installation.
- It is necessary that this manual is read and understood by these professionals and that they follow the instructions as detailed in this manual.
- Check all connections of the entire installation thoroughly, before putting the system into operation.
- Disconnect the device from power supply before opening or closing to avoid damages.
- Do not put a damaged product into operation and make sure that that does not happen inadvertently.
- A malfunction of the equipment should only be handled and fixed by authorized and qualified personnel
- If it is not possible to repair the malfunction, put the equipment out of operation and make sure that it cannot be put back into operation again.
- Repairs not described in this manual may only be carried out by the manufacturer or by the respective service organization.

Disclaimer of Liability

The manufacturer or their delegated representative is only liable in case of intend or gross negligence. The accountability is limited to the value of the order issued at the time to the manufacturer.

The manufacturer is not liable for damages, originated from disregarding the safety instructions or violating the instructions of the manual or operating conditions.

Consequential damages are excluded from the any liability.



1.2. Environmental aspects



The products from E+E Elektronik® are developed and designed in due consideration to the importance of the protection of the environment. Therefore, disposal of the product also should not lead to pollution of the environment.

The single-variety components must be separated before the transmitter is disposed of. The electronic components must be collected and as electronic scrap properly be disposed of.

2. PRODUCT DESCRIPTION


The flow meter of the series EE772, based on the measurement principle of thermal mass flow, is suited for the measurement of flow of air and gases in pipelines. Measurement of for instance the consumption of compressed air, nitrogen, helium, CO₂ or other non-corrosive and non-flammable gases.

The EE772 measures the volume flow at standard conditions according to DIN 1343 ($P_0=1023.25$ mbar; $t_0=273.15$ K or 0 °C (32 °F)). In addition to the standard volume flow, the measurand mass flow, norm flow and temperature are available.

The EE772 has an integrated consumption counter. The consumption quantity is indicated in the display and is not lost after a power failure. Two signal outputs are available. Depending on the application, the outputs can be configured as analogue (current or voltage), switch output or as pulse output for the measurement of the consumption.


1 Signal conditioning with optional display

The enclosure with the signal conditioning is mounted either on the measurement probe (model A or B compact) or is remote with a pluggable sensor cable up to 10 meter (33 feet) – (model C with remote probe).



2 Sensing probe with measurement electronics

The interchangeable sensing probe contains the sensor element and the measurement electronics, in which the data of the factory calibration is stored. The sensing probe is easy and quickly interchangeable in the field, independent of the electronics for the signal conditioning. After the exchange, the configuration of the outputs is unchanged.




3 Sensor cable (only by model C with remote sensing probe)

The sensor cable allows for the remote installation, up to 10 meter (33 feet), of the sensing probe from the housing with the signal conditioning.

4 Gauge mounting block


The gauge mounting block allows for the easy and reliable installation within the pipeline. During installation in the pipeline, observe the required inlet and outlet paths (see page 9). The nominal size of the gauge mounting block must match the nominal size of the pipe. The gauge mounting block is suitable for pressures up to 40 bar (580 PSI) and available for pipe diameters DN40 (1 1/2") to DN80 (3").



4a The gauge mounting block with hot tap valve allows for the installment and removal of the sensing probe under pressure without interrupting the process flow.

5 Screw cap



The screw cap, with female thread, is screwed in place if the flow meter is not installed and the pipeline has to be used.



3. INSTALLATION


3.1. Mounting dimensions

EE772-A / EE772-B Compact




dimensions in mm (inch)

EE772-C Remote probe




Drilling Plan:




The bottom part of the housing is mounted with 4 screws (not in the scope of supply).
Max. screw diameter: 4.5 mm (0.17 inch).
e.g. 4.2 x 38 mm DIN 7938H Screws

HA071xxx Gauge mounting block



HA072xxx Gauge mounting block with hot tap valve



pipe diameter	Thread	L	H
DN40 (1 1/2")	R _p or NPT 1 1/2"	110 (4.33)	108.5 (4.27)
DN50 (2")	R _p or NPT 2"	131 (5.16)	108.5 (4.27)
DN65 (2 1/2")	R _p or NPT 2 1/2"	131 (5.16)	108.5 (4.27)
DN80 (3")	R _p or NPT 3"	131 (5.16)	118.5 (4.67)

dimensions in mm (inch)

female thread:









Whitworth-Thread acc. EN 10226 (old DIN 2999) or NPT

3.2. Determining installation site

- The installation site should be easy accessible and free of vibrations and shocks.
- Observe at least 260 mm (10.24 inch) clearance above the housing with the signal conditioning, in order to be able to remove the sensing probe if necessary.
- The ambient temperature should not exceed the value as stated in the specifications (see page 20) – consider heating by radiation.
- Air purity on the installation site according to ISO 8573-1:2010: at least class 3.4.4
- The fluid should not condense at the installation site. Condensation on the tip of the sensing probe must be avoided.
- In compressed air systems, the installation must be downstream of the dryer. If there is no dryer, at least steam trap and suitable filter must be present.
- Observe the direction of the flow by the installation (see page 10).
- Observe the recommended straight pipe lengths up and downstream, in order to warrant the specified measurement accuracy.
- The flow meter should be installed as far as possible from any flow disturbance. Valves or check-valves should be installed in a respective distance from the flow meter.

3.3. Installation position

Make sure that the arrow on the tip of the sensing probe is pointing in the direction of the flow.


		Model	
		Compact	Remote
Vertical Mounting			
		+	++
Horizontal Mounting, sensor upwards			
		++	++
Horizontal Mounting, sensor downwards			
		-	-
Horizontal Mounting, sensor across			
		+	++







- ++ ... recommended installation position
- + not recommended if there is vibration on the pipeline
- not recommended

3.4. Required length of straight pipe

The flow meter should be installed as far as possible from disturbances of the flow. The causes for disturbance of the flow are for instance, reducers, elbows, T-pieces, valves, gate valves, etc. The specified measurement accuracy can be achieved only when the following straight inlet and outlet pipe lengths are installed:

- The wall thickness of the inlet and outlet pipe should be 2,6 mm
- The stated values are as a minimum. If possible, allow for greater distances.
- Valves or gate valves should be installed downstream of the flow meter.
- With lighter gases the inlet straight pipe should be longer.




	Type	(DN = Nominal Pipe Size)	
		Straight inlet pipe	Straight outlet pipe
	Extension	15 x DN	5 x DN
	Reduction	15 x DN	5 x DN
	90° - elbow	20 x DN	5 x DN
	Two 90° - elbows, in one level	25 x DN	5 x DN
	Two 90° - elbows, in two levels, T-piece	30 x DN	5 x DN
	Valve, gate valve	50 x DN	5 x DN

3.5. Assembly of the measurement section




In order to install or remove the gauge mounting block the pipeline system should be depressurized.

- All connections to be made with appropriated sealing material on the threads.
- The sealing material should not change the area of the inner cross section of the pipe. It must be warranted that the connections after installation are free of leaks.
- All fittings must be tested on seal tightness.
- Make sure during the assembly of the measurement section that the arrows on the pipe section and the gauge mounting blocks are pointing in the same direction as the flow.
- The recess for the alignment pin must be at the side of the outlet.



3.5.1. Assembly without flow meter, but with screw cap instead (blind cap)



In order to use the measurement section without the flow meter, the blind screw cap (in the scope of supply) must be screwed tight onto the opening of the gauge mounting block. If not needed the screw cap can be screwed and stored on the side of the gauge mounting block.

3.6. Installation of the flow meter sensing probe

3.6.1. Flow direction

The flow direction is indicated with an arrow on the tip of the probe. Due to the alignment pin is the installation of the sensing probe in the gauge mounting block only possible in the direction of the flow. After a removal, the sensing probe will be re-installed in the measurement section in exactly the same position as done at the factory. Hence, the highest reproducibility is guaranteed.



3.6.2. Installation of the sensing probe into the gauge mounting block




Make sure that the pipe line is depressurized!

- Remove transport protection cap of the head of the sensing probe.



- Mount the sensing probe in the gauge mounting block in such a way that the alignment pin fits in the recess on the gauge mounting block.



- Screw the retainer nut by hand so far that a certain resistance is noticeable.
- Check the correct installation position of the flow meter. The alignment pin must fit in the recess on the gauge mounting block.
- Tighten the red coloured retainer nut by hand. Tightening by hand should be sufficient. However, if the seal is not leak tight carefully tighten the nut with an appropriate tool a bit further



- The mechanical installation of the flow meter is therewith completed.

3.6.3. Installation of the sensing probe into the gauge mounting block with hot tap valve

The gauge mounting block with hot tap valve allows for the instalment and removal of the sensing probe under pressure, without interrupting the process flow.

! Operate the gauge mounting block with hot tap valve only with the hand, without tools!

Functionality:

Position OPEN - MEASURE: The sensor head is immersed into the pipe.

Position CLOSE - SERVICE: The gauge mounting block with hot tap valve pressure tight closed. You can remove the sensor probe.



OPEN-MEASURE



CLOSE-SERVICE

- Turn the gauge mounting block with hot tap valve in position CLOSE - SERVICE and mount the sensing probe in the gauge mounting block with hot tap valve in such a way that the alignment pin fits in the recess on the sealing cone.



- Screw the retainer nut by hand so far that a certain resistance is noticeable.
- Check the correct installation position of the flow meter. The alignment pin must fit in the recess on the sealing cone.
- Tighten the retainer nut by hand. Tightening by hand should be sufficient. However, if the seal is not leak tight carefully tighten the nut with an appropriate tool a bit further.
- Turn the gauge mounting block with hot tap valve in position OPEN - MEASURE.




- The mechanical installation of the flow meter is therewith completed.

4. ELECTRICAL CONNECTIONS

Before electrical connections are made turn off the power supply first. If not observed the electronics can be damaged as a result.

Only a qualified electrotechnical engineer may install the device.


- Unscrew the four screws and remove the cover of the housing.
- The screw terminals are located in the bottom part of the housing.
- For the electrical connection of the flow meter a six-wire cable is needed (e.g. 6 x 1 mm² (AWG 17))




4.1. Connection diagram

- Screw terminal OUT 1-1 for the analogue output is internally connected with GND.
- The housing should be grounded to achieve optimal electromagnetic compliance.

4.1.1. Relay and pulse output, internal switching



The relay switch and pulse outputs are both potential free.



Connection plug for the power supply and analogue outputs (rear view of the terminals)

Pin	Assignment
1	OUT 2-2
2	OUT 1-2
3	OUT 1-1
4	GND
5	OUT 2-1
6	n.c.
7	Vcc
8	n.c.

4.1.2. Connection with optional plug for power supply and outputs (order code Q)

4.2. Bus Output (optional)

4.2.1. M-Bus (Meter-Bus)

The M-Bus (Meter Bus) is a field bus for recording consumption data. Transmission is carried out serially on a reverse polarity protected two-wire line. The flow meter as M-Bus slave requires a separate supply voltage. No specific topology (line or star) is prescribed for the cabling. Normal telephone cable of type J-Y(St)Y Nx2x0.8mm can be used. A maximum of 250 meters is permitted per segment (primary addressed).

Read-out of the current measurement/consumption data

The following measurement/consumption values are transmitted during a standard query:

- Standard volumetric flow (32 Bit Real)
- Temperature (32 Bit Real)
- Mass flow (32 Bit Real)
- Consumption meter status (32 Bit Real)
- Flow velocity (32 Bit Real)

- Standard volumetric flow (32 Bit Integer)
- Temperature (32 Bit Integer)
- Mass flow (32 Bit Integer)
- Consumption meter status (64 Bit Integer)
- Flow velocity (32 Bit Integer)

The table below shows the package structure of the measurement/consumption data sent by the EE77x transmitter:

Header	
68	Start of telegram
4F 4F	L-field (length)
68	Second starting signal
08	C-field (RSP_UD)
XX	A-field (Adresse)
Start User data	
72	CI-field (variable data structure)
XX XX XX XX	Identification number
A5 16	Producer (0x16A5 ... EUE)
01	Version
00	Medium (0 ... others)
XX	Access number (continuous)
00	Status
00 00	Signature
Data record 1: Volumenstrom	
05	DIF (32 Bit Real)
3E	VIF (Volume flowmesse in m ³ /h)
XX XX XX XX	Act. measuring value
Data record 2: Temperatur	
05	DIF (32 Bit Real)
5B	VIF (Temperature in °C)
XX XX XX XX	Act. measuring value
Data record 3: Mass flow	
05	DIF (32 Bit Real)
53	VIF (Mass flow in kg/h)
XX XX XX XX	Act. measuring value
Data record 4: Consumption meter reading	
05	DIF (32 Bit Real)
16	VIF (Volume in m ³)
XX XX XX XX	Act. measuring value

Data record 5: Flow rate	
05	DIF (32 Bit Real)
7F	VIF (manufacturer specific in m/s)
XX XX XX XX	Act. measuring value
Data record 6: Volume flow	
04	DIF (32 Bit Integer)
3B	VIF (Volume flow in 10 ⁻³ m ³ /h)
XX XX XX XX	Act. measuring value
Data record 7: Temperatur	
04	DIF (32 Bit Integer)
59	VIF (Temperature in 10 ⁻² °C)
XX XX XX XX	Act. measuring value
Datenrecord 8: Mass flow	
04	DIF (32 Bit Integer)
51	VIF (Mass flow in 10 ⁻² kg/h)
XX XX XX XX	Act. measuring value
Datenrecord 9: Consumption meter reading	
07	DIF (64 Bit Integer)
13	VIF (Volume in 10 ⁻³ m ³)
XX XX XX XX	Akt. consumption data
XX XX XX XX	
Datenrecord 10: Flow rate	
04	DIF (32 Bit Integer)
7F	VIF (manufacturer specific in 10 ⁻² m/s)
XX XX XX XX	Act. measuring value
End of user data	
XX	Check sum
16	End of telegram

Secondary addressing

In addition to primary addressing, the EE77x transmitter provides the option of secondary addressing. The fields of identification number, manufacturer, version and medium are used together as the secondary address. The exact sequence of the secondary addressing is described in detail in the M-Bus Standard: <http://>

4.2.2. Modbus RTU

The measured values are stored as a 32Bit float value. Depending on the measurement unit selected, the measurements are saved in SI or US/GB units. The measurement unit can be changed using the configuration software.

For resetting the MIN/MAX-Values write 0 to the corresponding write register.

For Modbus protocol setting please see Application Note AN0103 (www.epluse.com/EE772).

Modbus Map:


Register	Protocol-Address	Measuring Value	SI-Unit	US/GB-Unit
Read Registers (Function Code 0x03 / 0x04) / 32Bit float Value				
30026	19	Standardized Flow	Nm/s	SFPM
30028	1B	Standardized Volumetric Flow	Nm ³ /h	SCFPM
30030	1D	Temperature	°C	°F
30032	1F	Massflow	kg/h	kg/h
30034	21	Consumption reading	m ³	ft ³
30036	23	Pressure	bar	psi
30261	104	MIN-Value Standardized Flow	Nm/s	SFPM
30263	106	MAX-Value Standardized Flow	Nm/s	SFPM
30265	108	MIN-Value Standardized Volumetric Flow	Nm ³ /h	SCFPM
30267	10A	MAX-Value Standardized Volumetric Flow	Nm ³ /h	SCFPM
30269	10C	MIN-Value Temperature	°C	°F
30271	10E	MAX-Value Temperature	°C	°F
30273	110	MIN-Value Massflow	kg/h	kg/h
30275	112	MAX-Value Massflow	kg/h	kg/h
30277	114	MIN-Value Pressure	bar	psi
30279	116	MAX-Value Pressure	bar	psi
Write Registers (Function Code 0x06) / 16Bit integer Value				
60261	104	Reset MIN/MAX-Value Standardized Flow		
60262	105	Reset MIN/MAX-Value Standardized Volumetric Flow		
60263	106	Reset MIN/MAX-Value Temperature		
60264	107	Reset MIN/MAX-Value Massflow		
60265	108	Reset MIN/MAX-Value Pressure		

4.2.3. Data Transmission


	Factory Setting	Adjustable Values	
		M-Bus	Modbus RTU
Baud Rate	9600	600...9600	9600...57600
Data Bits	8	8	8
Parity	Even	None, Odd, Even	None, Odd, Even
Stop Bits	1	1 or 2	1 or 2
Slave-Address	1	0...254	1...247

4.2.4. Addressing

The flow meters are factory-set to address 1. The slave address can be set via switches on the PCB.



Dip-Switch for address setting



Factory Setting:
Slave-Address = 1



Slave-Address = 255
The address set using the configuration software is used.


5. CONTROL COMPONENTS

5.1. Jumper J1 and J2

If the signal output is altered from relay to analogue output or vice versa, Jumper **Output 1** has to be relocated.

If the analogue output is altered from a current to a voltage output or vice versa, Jumper **Out-1** has to be relocated.

signal output 1 =
switching output



signal output 1 =
analogue output



Modbus RTU only




Line Termination = OFF



Line Termination = ON
150 Ohm parallel to
bus output A and B

Jumper Output 1

Jumper Line Termination



Jumper Out-1

analogue output = current signal (e.g. 4-20mA)

analogue output = voltage signal (e.g. 0-10V)


5.2. Digital interface USB (for configuration)

The USB connector is behind the blind screw cap, at the side of the housing.


- remove the blind screw cap with a screwdriver
- plug in the USB connector



Install the configuration software, which is in the scope of supply. The configuration software is available for downloading as well from our website at www.epluse.com




blind screw cap




USB-cable

5.3. Display / Indicator with keypad (optional)

An optional two-line display is available for the flow meter EE772. The display is an integral part of the cover of the housing and has two soft-keys for the control of the indicator.



Depending on the configuration of the outputs either the measured values, the status of the relay or the consumption is indicated.



Measurand		SI Unit	US Unit
v_0	Standardized Flow	m/s	SFPM
T	Temperature	°C	°F
\dot{V}_0	Standardized Volumetric Flow	m ³ /h; m ³ /min; l/min	SCFM; SLPM
m	Massflow	kg/h; kg/min; kg/s	kg/h; kg/min; kg/s
Q	Consumption	m ³	ft ³
p	Pressure	bar	psi


5.3.1. Indication of the analogue and pulse output

Line 1 indicates always the configured measurand at output 1. In line 2 the desired measurement value can be indicated using the UP and DOWN keys.


5.3.2. Indication of the switch output

Line 1 indicates the status of the switch output. In line 2 the desired measurement value can be indicated using the UP and DOWN keys.

The display shows an inverse image if the relay output is active (relay has switched).



Switch output inactive (relay has not switched)




Switch output active (relay has switched)


5.3.3. Indication of the MIN / MAX values

Keep the DOWN key pressed for > 3 sec to indicate the MIN value.

Keep the UP key pressed for > 3 sec to indicate the MAX value.




After that the several different measurement values can be indicated using the UP or DOWN keys.
Keep the DOWN or UP key pressed for > 3 sec to exit the MIN / MAX mode.



5.3.4. Reset of the consumption counter or the MIN / MAX value


Keep both the UP and DOWN key pressed for > 3 sec to enter the menu for resetting the consumption counter or the MIN / MAX value.

Select the desired menu item by pressing the UP or DOWN key briefly.



Press pushbutton UP and DOWN at the same time for >3s

To confirm the selected choice of the menu keep the DOWN or UP key pressed for > 3 sec.
Select menu item "NO" or "EXIT" to cancel without resetting.



5.3.5. Maximum consumption counter

The maximum consumption counter readout on the display is 999,999,999.0 m³ or 99,999,999.0 ft³. Then it shows "LCD maximum". The internal memory continues counting. The maximum counter reading is 3.4 * 10³⁸ m³. It is possible to read-out the counter reading with the configuration software.

6. ERROR MESSAGES

In case the flow meter is equipped with the optional display, the following error message can be indicated.

ERROR 01: sensing probe is not detected

- Cause: the sensing probe is not connect or is defect
- Effect: the display indicates "0" for all measurand. The analogue output defaults to the lowest configured value.
- Action: check the head of the sensing probe for visual damage.
check the sensor cable from the sensing probe to the electronics of the signal conditioning.

ERROR 02: the EEprom is defect

- Cause: the EEPROM for the storing of the consumption counter and MIN /MAX value is defect.
- Effect: the consumption counter and MIN / MAX values are no longer available. All measurement values though are still indicated. The analogue, relay and pulse output are still functional.
- Action: return the flow meter to the manufacturer.

7. MAINTENANCE

7.1. Removal of the sensing probe of the gauge mounting block



Gauge mounting block without hot tap valve Make sure that the pipe line is depressurized!

- Loose the retainer nut and pull the sensor probe from the gauge mounting block.
- Operation without the flow meter installed page 10.

7.2. Removal of the sensing probe of the gauge mounting block with hot tap valve

The sensor can be removed under pressure without flow interruption.

- Turn the gauge mounting block with hot tap valve with the hand without tools (anti-clockwise rotation) in the position SERVICE - CLOSE.
- Only if the gauge mounting block with hot tap valve is fully in the position SERVICE - CLOSE the sensor is hermetically sealed against the pressurized line.
- Loose the retainer nut slowly. Let the air exhaust slowly and make sure that is was only the relief pressure and the gauge mounting block with hot tap valve is hermetically sealed.
- Loose the retainer nut and pull the sensor probe from the gauge mounting block with hot tap valve.
- Operation without the flow meter installed page 10.



The sensor head is sensitive. Use the protection cap for transport and storage!

7.3. Cleaning of the sensor of the flow meter



Do not use an abrasive cleaning agent, an organic solvent containing halogen or acetone.

- Clean the head of the sensor probe by carefully swirling in warm water of isopropyl alcohol. It is recommended to use isopropyl alcohol if the pollution is crease or oil.



The sensor should not be touch by fingers or solid objects like screwdrivers or brushes!

- Leave the sensor to dry in ambient air.

8. REPLACEMENT PARTS / ACCESSORIES

8.1. Order Code Replacement Sensor

EE772-R-


Hardware Configuration			
Model	compact ri-le	direction od flow right to left	A
	compact le-ri	direction od flow left to right	B
	remote probe		C
Working range	high	(0,5...200 Nm/s) or (100...39370 ft/min)	H1
Measuring pipe - diameter	DN40		N040
	DN50		N050
	DN65		N065
	DN80		N080
Mounting	Gauge mounting block		M
	Gauge mounting block with hot tap valve		W
Plug ¹⁾	cable gland		A
	1 plug for power supply and outputs		Q

¹⁾ only for model A and B

Order Example

EE772-R-AH1N065MQ

Model: Compact ri-le
 Working range: high
 Measuring pipe - diameter: DN65
 Mounting: Gauge mounting block
 Plug: 1 plug for power supply and outputs



Order Example

EE772-R-CH1N065M

Model: remote probe
 Working range: high
 Measuring pipe - diameter: DN65
 Mounting: Gauge mounting block



9. TECHNICAL DATA

Measuring value

Flow

Measurand

Volumetric flow at standard conditions acc. DIN 1343
 $P_0 = 1013.25 \text{ mbar (14.7 PSI)}$; $t_0 = 0 \text{ }^\circ\text{C (32}^\circ\text{F)}$

Measuring range

standardized volumetric flow in air	DN40 (1 1/2"): low 2.26...452 Nm ³ /h 1.33...265.9 SCFM	high 2.26...904 Nm ³ /h 1.33...531.8 SCFM
	DN50 (2"): low 3.5...700 Nm ³ /h 2.06...411.9 SCFM	high 3.50...1400 Nm ³ /h 2.06...823.6 SCFM
	DN65 (2 1/2"): low 5.97...1400 Nm ³ /h 3.51...823.6 SCFM	high 5.97...1400 Nm ³ /h 3.51...823.6 SCFM
	DN80 (3"): low 9.04...1400 Nm ³ /h 5.32...823.6 SCFM	high 9.04...1400 Nm ³ /h 5.32...823.6 SCFM
standardized flow in air, CO ₂ , nitrogen	≤DN50 (2"): low 0.5...100 Nm/s 100...19685 SFPM	high 0.5...200 Nm/s 100...39370 SFPM
	DN65 (2 1/2"): low 0.5...117 Nm/s 100...23031 SFPM	high 0.5...117 Nm/s 100...23031 SFPM
	DN80 (3"): low 0.5...77 Nm/s 100...15157 SFPM	high 0.5...77 Nm/s 100...15157 SFPM
helium	≤DN50 (2"): low 0.5...100 Nm/s 100...19685 SFPM	high 0.5...120 Nm/s 100...23622 SFPM
	DN65 (2 1/2"): low 0.5...117 Nm/s 100...23031 SFPM	high 0.5...117 Nm/s 100...23031 SFPM
	DN80 (3"): low 0.5...77 Nm/s 100...15157 SFPM	high 0.5...77 Nm/s 100...15157 SFPM

Accuracy in air at 7bar (101.5 Psi) (abs) and 23°C (73°F)¹⁾ ± (1.5% of measuring value + 0.5% of full scale)

Temperature coefficient ± (0.1% of measuring value/°C)

Pressure coefficient ²⁾ 0.5% of measuring value / bar

Response time t_{90} < 1 sec.

Sample rate 0.5 sec.

Temperature

Measuring range -20...80 °C (-4...176 °F)

Accuracy at 20 °C (68 °F) ± 0.7 °C (1.26 °F)

Outputs

Output signal and display ranges are freely scalable

Analogue output voltage 0 - 10 V max. 1 mA
 current (3-wire) 0 - 20 mA and 4 - 20 mA $R_L < 500 \text{ Ohm}$

Switching output potential-free max. 44 VDC, 500 mA switching capacity

Pulse output Totalizer, pulse length: 0.02...2 sec.


Bus output (optional) Modbus RTU or M-BUS (Meter-Bus)

Digital interface USB (for configuration)

Input

Optional pressure compensation 4 - 20 mA (2-wire; 15 V) for pressure sensor

General

Supply voltage	18 - 30 V AC/DC	
Current consumption	max. 200 mA (with display)	
Temperature range	ambient temperature: -20...60 °C (-4...140 °F) medium temperature: -20...80 °C (-4...176 °F) storage temperature: -20...60 °C (-4...140 °F)	
Nominal pressure	40 bar (580 Psi)	
Humidity	no condensation	
Medium	compressed air or none corrosive gases	
Connection	cable gland M16x1.5 (optional connector M12x1 8pol.)	
Electromagnetic compatibility	EN61326-1	EN61326-2-3 
Material	housing	metal (AlSi3Cu)
	probe	stainless steel
	sensor head	stainless steel / glass
	measurement ball valve	brass
	Gauge mounting block	Aluminium
Housing protection class	IP65 / Nema 4	

1) The accuracy statement includes the uncertainty of the factory calibration with an enhancement factor k=2 (2-times standard deviation). The accuracy was calculated in accordance with EA-4/02 and with regard to GUM (Guide to the Expression of Uncertainty in Measurement).

2) The flow meter is calibrated at 7 bar (abs) 101.5 Psi. If the working pressure is different from 7 bar (101.5 Psi) you can compensate the error by setting the actual pressure with the configuration software.

9.1. Factory setting of outputs

SI-Unit

Analogue output [0...10 V / 0(4)...20 mA]		from	to		unit
			low (L1)	high (H1)	
standardized volumetric flow	DN40:	0	450	900	Nm ³ /h
	DN50:	0	700	1400	Nm ³ /h
	DN65:	0		1400	Nm ³ /h
	DN80:	0		1400	Nm ³ /h
mass flow	DN40:	0	570	1140	kg/h
	DN50:	0	890	1780	kg/h
	DN65:	0		1780	kg/h
	DN80:	0		1780	kg/h
standardized flow	DN40/50	0	100	200	Nm/s
	DN65	0		117,25	Nm/s
	DN80	0		77,41	Nm/s
temperature	all Ø	-20	80	80	°C
Switching output		[switching point/hysteresis]			
standardized volumetric flow	DN40:		360/36	720/72	Nm ³ /h
	DN50:		560/56	1120/112	Nm ³ /h
	DN65:			1120/112	Nm ³ /h
	DN80:			1120/112	Nm ³ /h
mass flow	DN40:		460/46	920/92	kg/h
	DN50:		700/70	1400/140	kg/h
	DN65:			1400/140	kg/h
	DN80:			1400/140	kg/h
standardized flow	DN40/50		80/8	180/18	Nm/s
	DN65			80/8	Nm/s
	DN80			60/6	Nm/s
temperature	all Ø		30/3	70/7	°C
Pulse output	pulse-value = 1m ³		pulse-duration = 0,1 sec.		

US-Unit

Analogue output [0...10 V / 0(4)...20 mA]

		from	to		unit
			low (L1)	high (H1)	
standardized volumetric flow	DN40:	0	260	520	SCFM
	DN50:	0	410	820	SCFM
	DN65:	0		820	SCFM
	DN80:	0		820	SCFM
mass flow	DN40:	0	570	1140	kg/h
	DN50:	0	890	1780	kg/h
	DN65:	0		1780	kg/h
	DN80:	0		1780	kg/h
standardized flow	DN40/50	0	19685	39370	SFPM
	DN65	0		23081	SFPM
	DN80	0		15238	SFPM
temperature	all Ø	-4	176	176	°F

Switching output

		[switching point/hysteresis]			
standardized volumetric flow	DN40:		210/21	420/42	SCFM
	DN50:		330/33	660/66	SCFM
	DN65:			660/66	SCFM
	DN80:			660/66	SCFM
mass flow	DN40:		460/46	920/92	kg/h
	DN50:		700/70	1400/140	kg/h
	DN65:			1400/140	kg/h
	DN80:			1400/140	kg/h
standardized flow	DN40/50		15000/1500	30000/3000	SFPM
	DN65			15000/1500	SFPM
	DN80			10000/1000	SFPM
temperature	all Ø		90/9	150/15	°F

Pulse output

pulse-value = 1CF

pulse-duration = 0,1 sec.

CONFIGURATION SOFTWARE

LIMITED LIABILITY

E+E Elektronik shall not be held liable for any damages or consequential damages (for example, but not restricted to, loss of earnings, interruption of business, loss of information and data or any other financial losses) resulting from the installation, use or impossibility of use of an E+E Elektronik software product and any associated support services or non-performance of support services.

1. General

The configuration software, in the scope of supply, allows for a user-friendly adaptation of the flow meter to the application. In addition, the measurement values for flow and temperature can be calibrated / adjusted.

The system requirements for the installation and execution of the software are:

- Windows XP with SP3, Windows Vista or Windows 7
- .NET framework 3.5 with SP1
- USB 2.0 interface

 During setup there will be no installation of .NET Framework 3.5 SP1 – if the required version is not already installed on the computer the following error message will appear at the start of the configuration software.



.NET Framework 3.5 SP1 can be installed using Windows Update.

2. Installation


In order to set up a smooth installation of the configuration software of the EE772, admin authorization for the personal computer is required.

- Place the CD-ROM in the drive tray of the computer.
- At this moment the EE772 should NOT be connected with the USB cable to the computer.
- The setup program will start automatically with the Auto Run-function – in case the program does not start automatically, one can start the setup software manually by starting Setup.exe directly.
- The InstallShield-Wizard for the EE772 configurator will be started.
- Follow the instructions on the screen to install the software.

i At first, the configuration software will be installed and then the installation of the USB driver activated – except if the user has defined that USB setup is disabled.
The USB driver will be automatically installed the moment the first connection is made with the EE772. The appearing dialog boxes can be dealt with the settings “No. do not download driver from the internet” and “Install the hardware automatically”.

If the EE772 configuration software and the USB driver are installed correctly, and the EE772 is connected via the USB interface with the personal computer, a connection “Silicon Labs CP210x USB to UART Bridge” should have been created in the device manager.


See: Start => Settings => Control Panel => System => Hardware => Device Manager




2.1. Configuration of the USB Interface (VirtualCOM)

After the startup of the software, the correct VirtualCOM interface for the USB driver must be configured


The number for the used USB interface can be found under:
Start => Settings => Control Panel => System => Hardware => Device Manager



The setting is done under menu “Extras” and menu item “Optional extras....”




Select the COM-port number as shown in the device manager.



i These settings are done only once and at the first start of the configuration software. The settings are stored for future use.


3. User Interface



- 1** Basic information:
After retrieving the data from the transmitter, the basic information of the device is shown here.
- 2** Status message:
Here are the messages shown about the status and other information.
- 3** Input screen:
Input screen for the configuration or adjustment of the flow meter.
- 4** Menu tool bar:
Selection of menu items.

4. Menu toolbar


4.1. File



Delete status message deletes the status messages.

Exit closes the configuration software.

4.2. Transmitter



Read reads the actual configuration of the transmitter.

Send uploads the 'new' configuration to the transmitter. The following settings are uploaded to the transmitter

- Units
- Output 1
- Output 2
- Display mode
- Pressure transmitter

Prior to uploading the 'new' configuration to the transmitter, a dialog box will show a summary of the changes. Click on the button 'OK' and the configuration will be uploaded to the transmitter; click 'Cancel' to cancel the operation.

4.3. Extras

Configurations of the VirtualCOM- interface (see page 23).

5. Input Screen

5.1. Output 1, Output 2

In this screen the actual settings of the transmitter for the output 1 and 2, resp. relay 1 and 2 are shown. The user can alter and upload these settings to the transmitter, together with other changes of the configuration.

5.1.1. Output mode

Here the mode of signal output can be determined.
Output 1: analogue or switch (relay) output
Output 2: switch (relay) or pulse output

i NOTE:
In case the mode of output 1 is changed, the Jumper J1 on the board of the signal conditioning electronics has to be relocated as well (see page 25)

5.1.2. Measurand

Here is determined which measurand will be represented at the particular output.

5.1.3. Units

Choice of the engineering units of the selected measurand in either SI- (m/s; °C; m³/h) or US-units (SFPM; °F; SCFM).

i NOTE:
The setting "Units" on the tabs for Output 1 and Output 2 are in sync with each other. If the units are changed on one of the output tabs, automatically the units on the other output tab are changed accordingly.

5.1.4. Output mode – analogue

Within the limits of measurement range and the scaling of the output, the analogue output can be freely configured and scaled. Either a standard output signal (0 – 5 V, 0 – 10 V, 0 – 20 mA, 4 – 20 mA) can be selected or a user defined range for the current / voltage output (e.g. 1 – 9 V).

NOTE: In case the analogue output is changed (from current to voltage or vice versa), the Jumper J2 on the board of the signal conditioning electronics has to be relocated as well (see page 25).

5.1.5. Output mode – switch (relay)

In the field for the “Switch-mode”, one can select “Hysteresis” or “Window”.

The field for “Type” is to determine the switch action of the relay, NO = Normally Open (activate to close), NC = Normally Close (activate to open).


Under “Measuring range” in the field “From” the low value of the measuring range can be entered and in the field “To” the high value.

The hysteresis of the set point is entered as a percentage of the measuring range.
[measuring range] = high measuring value – low measuring value

e.g. hysteresis
set point = 500 Nm³/h and reset point is 450 Nm³/h

Hysteresis = 50 Nm³/h = 0.5 % of measuring range


Hysteresis



When the measurement value reaches **set point 1**, the relay will be activated. The value at the reset point is the value at set point 1 minus the hysteresis.

e.g. set point 1 = 100 Nm³/h and the hysteresis 5 Nm³/h.
the relay switches at 100 Nm³/h. The reset point is at 96 Nm³/h.
Hysteresis = 5 Nm³/h = 5% of the measuring range

Window



The relay is activated as long as the measuring value is between the values of **set point 1** and **set point 2**. The hysteresis of each set point is fixed at 0.2% of the measuring range.

e.g.: set point 1 = 100 Nm³/h; set point 2 = 80 Nm³/h; hysteresis of each set point is 1 Nm³/h (0.2% of 500 Nm³/h)

set point	set point:	Hysteresis:	Measuring range
set point 1:	100.0000	0.2 %	0.0000 ... 1126.4541 m ³ /h
set point 2:	80.0000	0.2 %	From: 0.0000 m ³ /h
			To: 500.0000 m ³ /h

- ① 80 Nm³/h = set point 2
- ② 100 Nm³/h = set point 1
- ③ 99 Nm³/h = set point 1 - hysteresis
- ④ 79 Nm³/h = set point 2 - hysteresis

5.1.6. Output mode – pulse

If output 2 is configured for pulse, the measurand can be consumption only. Under “Pulse”, the duration of the pulse and the pulse value (Significance level of pulse) can be freely configured.


$$\frac{\text{Volume Flow [m}^3\text{/h]}}{\text{Pulse Value [m}^3\text{/Pulse]}} = \frac{\text{Number of Pulses}}{\text{Hour}}$$

The duration of the pulse can be set between 0.02 and 2 seconds.

Pulse	0.02 ... 2.00 sec
Pulse duration:	0.10 sec.
pulse-value:	1.000 m ³

e.g. Duration of pulse = 100ms; one pulse for each Nm³ consumed

The pulse – interval – ratio must be at least 1 : 2, meaning that the duration of the pulse interval must be at least twice the duration of the pulse itself.



Calculation of the minimum “pulse value” or the maximum “pulse duration”.

$$\text{IMPW_MIN} = \text{NORMV_MAX [m}^3\text{/h]} * \text{IMPL [s]} / 1200$$

$$\text{IMPL_MAX} = \text{IMPW [m}^3\text{]} * 1200 / \text{NORMV_MAX [m}^3\text{/h]}$$

IMPW	pulse value [m ³]
IMPL	pulse length (duration) [s]
IMPW_MIN	minimum pulse value [m ³]
IMPL_MAX	maximum pulse length (duration)
NORMV_MAX	expected maximum volume flow (Nm ³ /h)

5.2. Minimum flow shutdown

The minimum flow shutdown is switched on and off using the “active” checkbox.

If the output signal is ≤ than the set “Shutdown value”, the flow meter issues 0 on the analogue output.

Low flow cut-off	
<input checked="" type="checkbox"/> active	
Threshold:	50.00 m ³ /h
Hysteresis:	10.00 m ³ /h

5.3. Display

If an optional display is installed, at the tab Display the following items can be entered:

Drop-down input field "Display-Mode"

- Single spaced
- Double spaced (default)

Checkbox "Backlight"

- Checked = ON
- Unchecked = OFF

In the input field "Description (free text), a user specific name (max. 16 characters) for the transmitter can be entered.

e.g.: HALL 1

With the button "send" only the description will be uploaded to the transmitter.

5.4. Adjustment

The user can perform an adjustment for the measurands **normflow** and **temperature** in air.

The configuration software distinguishes between a 1-point and a 2-point adjustment automatically, depending on how many reference points for adjustments are entered.

The values entered for the customer's adjustment are stored in the electronics of the sensing probe and are therefore not lost if the electronics of the signal conditioning are replaced (see page 6)

If the checkbox "Performing customer-adjustment" is checked, the adjustment mode will be activated and the actual measuring value in the set interval automatically retrieved from the flow meter (transmitter).

i NOTE: At first change to "Calibration gas" in the tab "Process parameters". While the customer-adjustment is active all other pages, functions and commands are deactivated.

In the field "Adjustment" the measurand to be adjusted is selected.

In the field "Measuring value" the actual measurement value of the transmitter is indicated.

The update-interval can be set.

In the field "Reference value" the measurement value of the standard is entered.

After clicking the button "send" a control dialog box appears in which the values can be corrected if needed. Then the reference value will be uploaded to the flow meter (transmitter) and is the adjustment procedure complete.

The reference point of the customer-adjustment must be within the determined measuring range.

The customer-adjustment results in a slight rotation of the characteristic line, in such a way that the measurement deviation at the upper and lower adjustment points equals zero.


The configuration software determines, depending on its position, if it is an upper or lower adjustment point.

5.4.1. 1-point adjustment


	lower adjustment point	upper adjustment point
possibility 1	0 - 50% of measuring range	100% of measuring range
possibility 2	0% of measuring range	>50 - 100% of m.r.

m.r. ... measuring range

upper adjustment point at 80% of measuring range
 lower adjustment point automatically at 0% of m.r.



lower adjustment point at 20% of measuring range
 upper adjustment point automatically at 100% of m.r.




5.4.2. 2-point adjustment

With a 2-point adjustment procedure the lower adjustment point must be between 0 and 40% of the measuring range, and the upper adjustment point between 60 and 100% of the measuring range. If the adjustment point is between 40 and 60% of the measuring range, automatically a 1-point adjustment procedure will be executed instead.

	lower adjustment point	upper adjustment point
possibility 1	0 - <40% of m.r.	60 - 100% of m.r.
possibility 2	40 - <50% of m.r.	100% of m.r.
possibility 3	0% of m.r.	50 - <60% of m.r.

lower adjustment point at 10% of measuring range
 upper adjustment point at 90% of measuring range



5.4.3. Reset to factory settings

Customer-adjustment can be reset to the factory settings by checking the appropriate checkbox and subsequently clicking the “reset” button.

Reset to factory adjustment

Temperature customer-adjustment

Air velocity customer-adjustment

reset

5.5. Measuring values overview

The tab **measuring values** provides an overview of the retrieved actual measurement values of the flow meter (transmitter). Clicking on “Fetch values” will retrieve the actual measurement and MIN / MAX values for flow, volume flow, temperature, mass flow and pressure (only if a pressure transmitter is connected) from the transmitter – additional the reading of the consumption meter is retrieved as well.

Checking the “Polling” checkbox will retrieve the measuring data from the transmitter at the selected interval.

Measurand	Actual	Min	Max	Unit
Air velocity	1,279	0,500	1,412	m/sec
Volumetric flow rate	9,006	0,247	9,939	m³/h
Temperature	23,58	16,05	26,66	°C
Mass flow	11,483	0,315	12,672	kg/h
Pressure	2,029	0,000	2,047	bar

5.5.1. Reset of the MIN / MAX values

The MIN/ MAX values of each measurand, as stored in the flow meter (transmitter), can be reset by checking the appropriate checkbox and subsequently clicking the “Clear MIN / MAX” button.

Clear min-/max values

Air velocity

Volumetric flow rate

Temperature

Mass flow

Pressure

Clear min/max

5.5.2. Reset of the consumption counter (totalizer)

The reading of the consumption meter can be reset by clicking the “Reset meter” button.

Standard consumption meter

399.07 m³

Reset meter

5.6. Setting up Process Parameters

In the tab **Process Parameters** you can change the Process gas (medium) and set the pressure compensation

5.6.1. Change the Process Gas

i **NOTE:** This function is only active if the flow meter for a medium different from air has been ordered (see order code Medium in the data sheet)

Calibration-Gas: Is the gas (medium) in which the flow meter was calibrated in the factory. Unless otherwise specified, the flow meter is calibrated at the factory always in air.

Process-Gas: Is the gas (medium) in the measured process. The adjustable process gases are set at the factory and can be selected from a list.

Process gas

Calibration gas Process gas: CO2

Process gas change to: 3: CO2

Description:
CO2

The flow meter is factory set to the ordered gas (medium).
 If the setting for the process-gas modified or changed between calibration- and process gas, the changed setting has to be sent to the transmitter. Use “send data to the transmitter and read ...” button.
 The “active gas” to which the flow meter is set, you can see in the field basic information.

Units	US
Process gas	CO2
Active gas	Calibration gas
Computation version	1

5.6.2. Changing the standard conditions

The flow meter is factory-set to standard conditions conforming to DIN 1343.

Factory setting: $P_0 = 1013.25 \text{ mbar}$, $t_0 = 0^\circ\text{C}$ (273.15 K)

The corrected volume flow measured value is calculated in line with the standard conditions set.

System values

Standard conditions: °C

mbar

5.6.3. Pressure compensation

To achieve the highest measuring accuracy, the actual pressure can be entered in the field “pressure”.
 The “Send” button is used only to send the process pressure to the transmitter.

Cycle pressure (absolute) bar

5.7. External pressure transmitter for pressure compensation

In order to achieve the highest accuracy, the input from an external pressure transmitter will be very useful if the pressure fluctuates strongly (e.g. 3 to 10 bar (45 to 150 psi)). An absolute pressure transmitter with a 2-wire loop powered 4 – 20 mA output should be used.

On the tab “Pressure transmitter” the measuring range can be entered.

Measuring range

Transmitter type:

From: bar

To:

Output range

Output signal:

5.8. Bus configuration

If the flow meter is equipped with an optional bus module, the data transfer rate and the network address can be set on the “Bus configuration” tab.

The network address set is only used when the dip switches on the flow meter PCB are set to 255 (see page 14).

Communication parameter

Baud rate:

Parity:

Stop bits:

Bus protocol:

Network address:

HEAD OFFICE:

E+E ELEKTRONIK Ges.m.b.H.

Langwiesen 7
A-4209 Engerwitzdorf
Austria
Tel: +43 7235 605 0
Fax: +43 7235 605 8
info@epluse.com
www.epluse.com

SALES OFFICES:

E+E CHINA / BEIJING

Tel: +86 10 84992361
info@epluse.cn www.epluse.cn

E+E CHINA / SHANGHAI

Tel: +86 21 61176129
info@epluse.cn www.epluse.cn

E+E GERMANY

Tel: +49 6172 13881 0
info@epluse.de www.epluse.de

E+E FRANCE

Tel: +33 4 7472 35 82
info@epluse.fr www.epluse.fr

E+E ITALY

Tel: +39 02 2707 8636
info@epluse.it www.epluse.it

E+E KOREA

Tel: +82 31 732 6050
info@epluse.co.kr www.epluse.co.kr

E+E USA

Tel: +1 508 530 3068
office@epluse.com www.epluse.com